

MITEQ SEALERS 103/104

APPLICATION PROCEDURE

Fixing and installation of tiles and stonework to be in accordance with adhesive manufacturers recommendations.

Acid wash installed pavers and stonework using Miteq Cleaner 304
Diluted 1 Part to 12 Parts clean cool water. Carry out follow up rinse and leave clean.

Ensure all grout haze and spoil is removed.

Vacuum up free water and allow to dry. Do not Apply Sealers 103/104 to a damp surface.

Apply Sealers directly from can. Do not thin. Apply evenly with a medium nap roller, lambswool pad or low pressure spray. A wet on wet application is suitable

Do not apply excessively or allow material to pond. Allow to cure 24 hours prior to placing into light service.

PRACTICAL COMPLETION

Add Miteq Cleaner 301 diluted 1 Part to 50 Parts warm Clean water. Use power scrubber or hand rotary Scrubber with soft scourer pad.

Ensure soil is totally removed
Repeat if necessary. Leave clean and dry.

DAILY MAINTENANCE

Use ride on scrubber or hand rotary machine with soft scourer pad.

Use cleaner 301 diluted 1 Part to 50 Parts warm water.

Vacuum up excess water.

Allow surface to totally dry prior to foot traffic

WEEKLY MAINTENANCE

Treat as for daily clean if required.

Spot remove marks, soil etc. with hand mop or hand scrubber pad with diluted 301 Cleaner as previous.

Soils such as animal droppings should be treated with diluted cleaner 303, hosed off and allowed to dry.

MONTHLY+ MAINTENANCE

Prepare and clean as for daily maintenance

Monitor effectiveness of sealer/s at 6 monthly intervals.

Re-application of Sealers 103/4 is to be carried out over a clean surface. Removal of existing sealer is not required. Ensure soils are removed prior to re-application to prevent staining of surface.

Leave surface smooth and clean prior to re-application. Re-apply as per original installation specification.

Read data sheet and safety data prior to commencement.