

# MITEQ SEALERS 201/202

## APPLICATION PROCEDURE

Fixing and installation of tiles to be  
In accordance with adhesive manufacturers recommendations.

Acid wash installed pavers using Miteq Cleaner 304 Diluted 1 Part to 12 Parts clean cool water. Carry Out follow up rinse and leave clean.

Ensure all grout haze and spoil is removed.

Vacuum up free water and allow to dry. Do not Apply Sealers 201/ 202 to a damp surface.

Apply Sealer 202 Non-Slip directly from can. Do not thin. Apply evenly with a medium nap roller. Allow first coat To cure prior to application of second coat.

Do not apply excessively or allow material to pond. Allow to cure 24 hours prior to placing into service.

## PRACTICAL COMPLETION

Add Miteq Cleaner 301 diluted 1 Part to 50 Parts warm Clean water. Use power scrubber or hand rotary Scrubber with soft scourer pad.

Ensure soil is totally removed Repeat if necessary. Leave clean and dry.

## DAILY MAINTENANCE

Use ride on scrubber or hand rotary machine with soft scourer pad.

Use cleaner 301 diluted 1 Part to 50 Parts warm water.  
Vacuum up excess water.

Allow floor to totally dry prior to foot traffic

## WEEKLY MAINTENANCE

Treat as for daily clean if required.

Spot remove marks, soil etc. with hand mop or hand scrubber pad with diluted 301 Cleaner as previous.

## MONTHLY+ MAINTENANCE

Prepare and clean as for daily maintenance

Slip resistance should be monitored at 3 monthly intervals.

Re-application of Sealers 201 & 202 is to be carried out over a clean surface. Sealers are solvent sensitive, removal of existing coating is not required unless surface is damaged or flaking.

Feather back edges and leave smooth and clean prior to re-application. Re-apply as per original installation

Read data sheet and safety data prior to commencement.